

Operator's MANUAL

KLP SERIES LEVER CHAIN HOISTS

Mod. No. KLP-75

KLP-150

KLP-300

KLP-600

KLP-75L

KLP-150L

KLP-300L

KLP-600L



TABLE OF CONTENTS

Waranty Policy	2, 3	Warnings	3
Introduction	4	Specifications	4
Unpacking, Assembly and Setup	4	Inserting Wire Rope	5

ONE YEAR LIMITED WARRANTY

JET® Lever Chain Hoists are guaranteed to be free of defects in material and workmanship. If one of these products fails during the first year of operation due to defective material or workmanship it will be repaired or replaced at our discretion. Normal wear and tear on moving parts is excluded from this guarantee. This guarantee does not apply to any product showing signs of misuse, overloading, alteration, or improper maintenance.

WARRANTY PROCEDURE

After receiving authorization from one of the offices listed below, any product for which there is a warranty claim must be returned prepaid to an authorized JET® warranty depot along with proof of purchase.

For information on JET® Material Handling products, warranty depots or distributors, contact:

Vancouver	Edmonton	Winnipeg	Toronto	Montreal
Tel: (604) 523-TOOL (8665)	Tel: 1-800-472-7685	Tel: (204) 632-6970	Tel: (905) 565-8661	Tel: (514) 332-4618
Toll Free: 1-800-472-7685	Fax: 1-800-663-7742	Fax: (204) 694-9534	Fax: (905) 565-7266	Fax: (514) 332-4777
Fax: (604) 526-JET1 (5381)				
Toll Free: 1-800-663-7742				

INFORMATION FOR YOUR SAFETY

It is the responsibility of the owner/user to install, inspect, test, maintain, and operate these lever hoists in accordance with ASME B30.21, Safety Standard for Manually Operated Lever Hoists.

These general instructions deal with the normal installation, operation and maintenance situations encountered with the lever hoists described herein. The instructions should not be interpreted to anticipate every possible contingency or to anticipate the final system or configuration that uses these lever hoists.

These instructions include information for a variety of lever hoists. Therefore, all instructions and information may not apply to one specific lever hoist. Disregard those portions of the instructions that do not apply.

If the lever hoist owner/user requires additional information, or if any information in these instructions are not clear, contact your local JET® Material Handling Products distributor.

This lever hoist should not be installed, operated, or maintained by any person who has not read all the contents of these instructions, and ASME B30.21, Safety Standard for Manually Operated Lever Hoists. Failure to read and comply with these instructions or any of the warnings or limitations noted herein can result in serious bodily injury or death, and/or property damage.

Only trained and qualified personnel shall operate and maintain this equipment.

Equipment described herein is not designed for, and should not be used for lifting, supporting, or transporting people.

User should not use this lever hoist in conjunction with other equipment unless necessary and/or required safety devices applicable to the system are installed by the user.

Modifications to upgrade, rerate or otherwise alter these lever hoists shall be authorized only by the original equipment manufacturer or qualified professional engineer.

PRIOR TO INSTALLATION

Check for damage during shipment. Place claim with carrier if any damage is discovered. DO NOT install or use a damaged lever hoist.

Check and verify that structure or other equipment that will support the lever hoist has a rated load capacity equal to or greater than the rated load capacity of the lever hoist to be used.

OPERATION

Before initial operation of hoist:

1. Read and comply with all instructions and warnings furnished with or attached to lever hoist.
2. Check lubricant.
3. Check operation of brake.
4. Check that chain is properly seated in sheaves and that chain is not twisted, kinked, or damaged.

Before each shift:

1. Inspect hooks for nicks, gouges, cracks, and signs of pulling apart or twisting.
2. Inspect hook latch for proper operation.
3. Check chain for kinks or twists.
4. Check operation of brake.
5. Replace warning label if missing or illegible.

Before operating:

1. Be certain all personnel are clear of the load to be lifted and moved.
2. Make sure load will clear stock piles, machinery, or other obstructions when hoisting and travelling the load.
3. Eliminate any twists or kinks in the load chain.

SAFETY PRECAUTIONS

A. **READ** these instructions and ASME B30.21, Safety Standard for Manually Operated Lever Hoists before installing, operating, or maintaining this equipment.

B. **WARN** personnel of approaching loads.

C. DO NOT

- | | |
|--|---|
| 1. Lift more than rated load. | 12. Operate with other than hand power. |
| 2. Operate lever hoist when it is restricted from forming a straight line with the direction of loading. | 13. Remove, deface, or obscure warning label or labels on lever hoist. |
| 3. Operate with twisted, kinked, or damaged chain. | 14. Leave load suspended when lever hoist is unattended unless specific precautions have been instituted and are in place. |
| 4. Operate if chain is not seated in sheaves or sprockets. | 15. Lengthen load chain or repair damaged load chain by welding. |
| 5. Wrap chain around load or use chain as a sling. | 16. Use chain as a ground for welding. |
| 6. Operate unless load is properly applied to the saddle or bowl of the hook. | 17. Hammer on lever. |
| 7. Operate if load is applied to the tip of the hook. | 18. Use extensions on lever. |
| 8. Operate with damaged or missing hook latches. | 19. Lift one load with more than one lever hoist, unless each lever hoist is rated to support the entire load in the event one or more lever hoists is disabled, shifting load to the other lever hoists. |
| 9. Lift people or lift loads over people. | |
| 10. Operate with side-pulling or side-loading of load to lever hoist. | |
| 11. Operate a damaged or malfunctioning lever hoist. | |

OPERATION

TO RAISE LOAD:

1. Set change lever on handle to "UP" position.
2. Operate handle to move load.

TO LOWER LOAD:

1. Set change lever on handle to "DOWN" position.
2. Operate handle to move load.

TO ADJUST CHAIN LENGTH:

TO SHORTEN:

Set change lever to "NEUTRAL" and turn feed hand wheel clockwise or pull free end of chain.

TO LENGTHEN:

Set change lever to "NEUTRAL" and turn feed hand wheel counter-clockwise or pull hook end of chain.

BRAKE LOCK:

If the lever hoist is unloaded by means other than operating the lever, or if the bottom hook is pulled tight against the hoist body, brake lock can occur. To unlock brake, move selector to DOWN position and pull sharply on lever.

SHOCK LOADS:

Do not allow a load to drop, such as over the edge of a platform, while connected to a lever hoist. The sudden drop, even of an insignificant distance, can cause a severe momentary overload, seriously damaging the lever hoist and possibly resulting in the loss of the load. This can occur at loads well under the rated capacity.

Replacement of Chain:

Use only genuine JET grade 100 replacement load chain.

INSPECTION AND MAINTENANCE

Prior to initial use, all new, modified, and repaired hoists shall be inspected in accordance with Table 2. Thereafter, inspections shall be conducted at intervals shown in Table 1; and items to be inspected are indicated in Table 2 by F (Frequent) or P (Periodic).

Frequent Inspections – Visual inspection by the operator or other authorized person. This inspection includes listening for unusual sounds while the hoist is operated that may indicate deficiencies.

Periodic Inspections – Audible-visual inspection as for Frequent Inspections, with some disassembly to allow a more detailed inspection if external conditions indicate the need.

Exception: Brakes require more than audible-visual inspection. Check daily by operating lever hoist with and without load, stopping at various positions to test holding power and amount of drift, if any occurs.

TO ADJUST BRAKE:

1. Remove cotter pin from castle nut on feed knob.
2. Screw castle nut on snugly, then back nut off just enough to line up holes for cotter pin. Replace cotter pin.

TABLE 1 – FREQUENCY OF INSPECTION

SERVICE	FREQUENT (F) INSPECTION	PERIODIC (P) INSPECTION
Normal	Monthly	Annually
Heavy	Weekly to Monthly	Semi-Annually
Severe	Daily to Weekly	Quarterly

TABLE 2 – INSPECTION CHART

In chart, F indicates Frequent Inspection, P indicates Periodic Inspection

LOCATION	CHECK FOR	F	P
Braking mechanism	Slipping under load	✗	
	Hard to release	✗	
Brake Parts	Glazing		✗
		Oil contamination	
Brake Discs			
Pawl; Ratchet	Excessive wear		✗
Pawl Spring	Corrosion; stretch		✗
Hooks	Chemical damage	✗	
	Deformation	✗	
	5% in excess of normal throat opening		✗
	10° twist from plane of unbent hook		✗
	Cracks (dye penetrant, magnetic particle, or other suitable detection method)		✗

LOCATION	CHECK FOR	F	P
Hook Retaining Members (Pins, Bolts, Nuts)	Not tight or secure		✗
	Hook Latch	Damaged; does not close	✗
Suspension Members (Sheaves, hand-wheels, chain attachments, suspension bolts or pins)	Excessive wear		✗
	Cracks	✗	✗
Gears	Distortion		✗
	Broken or worn teeth		✗
	Cracks		✗
Load Block; Suspension Housing	Inadequate lubrication		✗
	Distortion	✗	✗
Trolley; Supporting Structure	Cracks	✗	✗
	Possible inability to continue supporting imposed loads		✗
Bolts, Nuts, Rivets	Not tight or secure		✗
WARNING Label	Removed or illegible	✗	

Refer to ASME B30.21 for additional information on inspection, test, and maintenance.

HOOKS

WARNING

1. Any hook that requires replacement because of excessive bends, twists, or throat opening indicates abuse or overloading of the hoist. Therefore, other load-supporting components of the lever hoist should be inspected for possible damage when such conditions are found.
2. Never repair hooks by welding or reshaping. Heat applied to the hook will alter the original heat treatment of the hook material and reduce the strength of the hook.
3. Never weld handles or other attachments to the hook. Heat applied to the hook will alter the original heat treatment of the hook material and reduce the strength of the hook.

HOOKS INSPECTION

Refers to ASME B30.10, Safety Standard for Hooks. Inspect hooks and measure hook throat opening at least once a month. Between regular inspections check visually daily for deformation, distortion, twisting, damage, and missing or damaged hook latches. Inspect as follows:

1. Measure hook opening at raised dots to check for stretch. Raised dots provide a constant reference point and eliminate measurement errors. Replace hook when measurement between dots reaches “Dimension Y Replace Hook” figures below.

CAPACITY TONS	DIMENSION Y NEW HOOK	DIMENSION Y REPLACE HOOK	DIMENSION H NEW HOOK	DIMENSION H REPLACE HOOK
3/4	37.5mm	39.8mm	19.5mm	18.5mm
1-1/2	47mm	50mm	25mm	24mm
3	62.5mm	66mm	35.5mm	34mm
6	78mm	83mm	43.2mm	41mm




Figure 1

2. Measure hook depth at load bearing point in the bowl of the hook. Hook must be replaced when wear at load bearing point reaches “Dimension H Replace Hook” figures.
3. A bend or twist of the hook exceeding 10° from the plane of the unbent hook requires replacement of the hook.
4. A hook latch that is missing shall be replaced.
5. A hook latch that is inoperative shall be repaired or replaced.
6. A hook with a hook latch that does not close the throat opening of the hook shall be removed from service until the latch is replaced or repaired.
7. Hooks having damage from chemicals, corrosion, or deformation shall be repaired or replaced.

Due to variations in the manufacturing process, the dimensions of a new hook are variable. For accurate record keeping, we recommend users record measurements Y and H of the hook before use. Record this information in the spaces below and calculate the replacement value by multiplying by 1.05 for Dimension Y or by 0.95 for Dimension H.

CAPACITY TONS	DIMENSION Y NEW HOOK	DIMENSION Y REPLACE HOOK
3/4		
1-1/2		
3		
6		

CHAIN

Inspect chain at least once a month. Between regular inspections, check visually daily for nicks, gouges, weld splatter, corrosion, or distorted links. Inspect chain thoroughly if it does not feed smoothly over load sheaves. Inspect as follows:

1. Clean chain with solvent before inspection.
2. Test hoist with load and observe operation of chain over load sheaves.
3. Slacken chain and inspect contact points for excessive wear. Refer to Figure 2.
4. Using caliper-type gauge, measure inside length of 5 links under light tension. Refer to Figure 3. Replace chain if measurement exceeds maximum allowable gauge length as follows:

CAPACITY TONS	CHAIN WIRE DIAMETER	5 LINKS NORMAL	5 LINKS MAXIMUM
3/4	5.6mm	85mm	87.5mm
1-1/2	7.1mm	105mm	108mm
3 + 6	10.0mm	150.0mm	154.5mm




Figure 2




Figure 3

DISASSEMBLING AND ASSEMBLING

You will occasionally want to disassemble your lever hoist for cleaning. To do so, proceed as follows:

To disassemble gear case:

1. Lay tool on side, gear case facing up.
2. Disconnect four hexnuts on gear casing.
3. Lift off gear casing.
4. Remove dirt from surfaces, using solvent or rag.

To assemble gear case:

1. Place gear case back on bolts, matching gear shafts to bearings on interior of gear casing.
2. Secure firmly with four hexnuts.

To disassemble brake and lever for cleaning:

1. Place tool on side, feed handwheel facing up.
2. Remove cotter pin from castle nut in handwheel.
3. Remove castle nut and washer.
4. Lift off feed handwheel and stop knob.
5. Remove two hexnuts from back of lever, and one bolt from front of lever.
6. Remove four hexnuts on side of brake cover.
7. Unscrew change over gear, then lift off brake cover. Brake is now visible.
8. Remove brake and linings, keeping track of sequence of removal.
9. Remove dirt from surfaces, using solvent or rag. If brake linings show wear or cracks, replace.

To assemble brake:

1. Set brake and linings back into place.
2. Replace spring.
3. Place brake cover back on bolts, securing with hexnuts.
4. Replace change over gear #23
5. Replace stop knob #31 on Pinion Shaft #8. Position so that TAB on stop is at 15-20 degree angle to raised limiter on right side of change over gear. See figure 4 for correct position.
6. Turn change over gear counter clockwise until raised limiter contacts TAB on stop knob. See figure 5.
7. Replace lever and secure with hexnuts.
8. Replace feed hand wheel, ensure slot on back of hand wheel engages tab on change over gear.
9. To set brake:
 - Screw castle nut on snugly, then reverse only far enough to line up holes for cotter pin.
 - Insert cotter pin and secure with proper tool.




Figure 4





Figure 5

KLP LEVER HOIST PRODUCT KLP-75, KLP-150, KLP-300, KLP-600



ITEMS WITH L AFTER REF # FOR OVERLOAD SYSTEM ONLY

KLP LEVER HOIST PRODUCT KLP-75, KLP-150, KLP-300, KLP-600

REF	PART NUMBER KLP-75	PART NUMBER KLP-150	PART NUMBER KLP-300	PART NUMBER KLP-600	DESCRIPTION	REQ
1	PVI-KLP75-1	PVI-KLP150-1	PVI-KLP300-1	PVI-KLP600-1	LEFT SIDE PLATE ASSEMBLY	1
2	PVI-KLP75-2	PVI-KLP150-2	PVI-KLP300-2	PVI-KLP600-2	SPROCKET	1
3	PVI-KLP75-3	PVI-KLP150-3	PVI-KLP300-3	PVI-KLP600-3	CHAIN GUIDE	2
5	PVI-KLP75-5	PVI-KLP150-5	PVI-KLP300-5	PVI-KLP600-5	TOP HOOK ASSEMBLY, 4,5,47,48	1
6	PVI-KLP75-6	PVI-KLP150-6	PVI-KLP300-6	PVI-KLP600-6	RIGHT SIDE PLATE ASSEMBLY	1
7	PVI-KLP75-7	PVI-KLP150-7	PVI-KLP300-7	PVI-KLP600-7	SPLINED GEAR	1
8	PVI-KLP75-8	PVI-KLP150-8	PVI-KLP300-8	PVI-KLP600-8	DRIVING PINION	1
8L	PVI-KLP75-8L	PVI-KLP150-8L	PVI-KLP300-8L	PVI-KLP600-8L	DRIVING PINION OVERLOAD	1
9	PVI-KLP75-9	PVI-KLP150-9	PVI-KLP300-9	PVI-KLP600-9	PINION SHAFT & DISC GEAR	1
10	PVI-KLP75-10	PVI-KLP150-10	PVI-KLP300-10	PVI-KLP600-10	GEAR COVER ASSEMBLY	1
11	PVI-KLP75-11	PVI-KLP150-11	PVI-KLP300-11	PVI-KLP600-11	LOCKING NUT	8
12	PVI-KLP75-12	PVI-KLP150-12	PVI-KLP300-12	PVI-KLP600-12	CHAIN STRIPPER	1
13	PVI-KLP75-13	PVI-KLP150-13	PVI-KLP300-13	PVI-KLP600-13	BRAKE SEAT	1
13L	PVI-KLP75-13L	PVI-KLP150-13L	PVI-KLP300-13L	PVI-KLP600-13L	BRAKE SEAT OVERLOAD	1
14	PVI-KLP75-14	PVI-KLP150-14	PVI-KLP300-14	PVI-KLP600-14	PAWL SPRING	2
15	PVI-KLP75-15	PVI-KLP150-15	PVI-KLP300-15	PVI-KLP600-15	PAWL	2
16	PVI-KLP75-16	PVI-KLP150-16	PVI-KLP300-16	PVI-KLP600-16	BUSHING	1
17	PVI-KLP75-17	PVI-KLP150-17	PVI-KLP300-17	PVI-KLP600-17	FRICTION DISC (1 SET = 2 PCS)	1
18	PVI-KLP75-18	PVI-KLP150-18	PVI-KLP300-18	PVI-KLP600-18	RATCHET DISC	1
18L	PVI-KLP75-18L	PVI-KLP150-18L	PVI-KLP300-18L	PVI-KLP600-18L	FUSED BRAKE DISC	1
20	PVI-KLP75-20	PVI-KLP150-20	PVI-KLP300-20	PVI-KLP600-20	SPRING	1
20L	PVI-KLP75-20L	PVI-KLP150-20L	PVI-KLP300-20L	PVI-KLP600-20L	SPRING OVERLOAD	1
23	PVI-KLP75-23	PVI-KLP150-23	PVI-KLP300-23	PVI-KLP600-23	CHANGE OVER GEAR	1
23L	PVI-KLP75-23L	PVI-KLP150-23L	PVI-KLP300-23L	PVI-KLP600-23L	OVERLOAD LIMITER ASSY	1
19	PVI-KLP75-19	PVI-KLP150-19	PVI-KLP300-19	PVI-KLP600-19	HANDLE COVER ASSEMBLY	1
24	PVI-KLP75-24	PVI-KLP150-24	PVI-KLP300-24	PVI-KLP600-24	CHANGE OVER PAWL ASS 25,26	1
27	PVI-KLP75-27	PVI-KLP150-27	PVI-KLP300-27	PVI-KLP600-27	HANDLE SLEEVE	1
28	PVI-KLP75-28	PVI-KLP150-28	PVI-KLP300-28	PVI-KLP300-28	LEVER HANDLE ASSY	1
30	PVI-KLP75-30	PVI-KLP150-30	PVI-KLP300-30	PVI-KLP600-30	HAND WHEEL ASSY 31,32,33,34	1
30L	PVI-KLP75-30L	PVI-KLP150-30L	PVI-KLP300-30L	PVI-KLP600-30L	HAND WHEEL OVERLOAD	1
31L	PVI-KLP75-31L	PVI-KLP150-31L	PVI-KLP300-31L	PVI-KLP600-31L	STOP KNOB	1
36	PVI-KLP75-36	PVI-KLP150-36	PVI-KLP300-36	PVI-KLP600-36	END CHAIN RING	1
37	PVI-KLP75-37	PVI-KLP150-37	PVI-KLP300-37	PVI-KLP600-37	BOTTOM HOOK ASSEMBLY	1
47	PVI-KLP75-47	PVI-KLP150-47	PVI-KLP300-47	PVI-KLP600-47	SAFETY LATCH KIT	1

