

## REPLACEABLE CAST IN PLACE *Installation Instructions*

The following instructions apply to Access® Tile's Replaceable Cast in Place tiles as well as the Radius Curve and Wayfinding version of these tiles.

1. Maintaining a 4 - 7 slump range, pour and float the concrete.
2. Without removing any concrete, place the tile 6" - 8" from the curb line (face of curb).
3. Tamp the tile in grid pattern across the top face, embedding the tile into the concrete using a non-marring rubber mallet.
4. Place sandbags or 25 lb. weights on the tile to prevent floating and create an edge around the perimeter of the tile using a 3/8" radius edging tool then float the concrete around the tile's perimeter using a steel trowel.
5. Apply a broom-finish to the surrounding concrete.
6. After the concrete has substantially cured, remove the protective plastic wrap by cutting the plastic with a sharp knife tight to the concrete / tile interface.

**NOTE:** If concrete bled under the plastic, a soft wire brush will residue without damaging the tile.



## *Replacement Instructions*

- A. Unscrew T27 tamper-proof fasteners.
- B. Tap the perimeter of the tile with a rubber mallet to remove the bond of the tile to the concrete.
- C. Use a pry bar to pry up an edge. Remove all debris from the vacant cavity mold. Vacuum / sweep all crevices.
- D. Insert replacement tile, gently apply pressure to seat tile in recess. Reinsert tamper-proof fasteners in hex-shaped concrete anchors.

*Tiles can be cut to custom sizes, or to make a radius, using a continuous rim diamond blade in a circular saw or mini-grinder. Use of a straightedge to guide the cut is advisable where appropriate.*

