

21 PC BALL JOINT MASTER SERVICE KIT

Product # H3536 | Model #



- For press fit vehicle components
- Removes and installs ball joints, universal joints, truck brake anchor pins, and 4WD ball joints
- C-frame can be used alone to remove/replace universal joints
- Fits most Dodge® Ram, Ford®, GM®, IHC® and Jeep® 2 and 4 wheel drive pick-up trucks, SUV's and vans with Dana® front axles
- Kit includes:
 - 1 c-frame press with screw (1.106" x 7tpi)
 - 7 receiving tubes
 - 4 receiving cups
 - 1 receiving cup adapter
 - 2 installation cups
 - 1 installation adapter
 - 1 removal adapter
 - 1 centre plug
 - 1 remover/installer
 - 1 blow mould case

